

Installation Instructions for the No Touch Toilet Seat

1. With care, remove old toilet seat.
2. After removal, clean the surface area around and inside the attachment holes on your toilet.
3. Insert the two attachment screws with the toilet seat into the mounting bracket. Then insert the small arm into the seat clip. This forms the entire seat assembly.
4. Position the toilet seat assembly so the attachment screws on the bracket align with the toilet attachment holes.
5. Position the seat assembly in a closed position.
6. Tighten the attachment screws securely. There is no need to over tighten.
7. Raise the seat using the foot pedal so the foot pedal rests approximately one-half inch above the floor.
8. Tighten the adjustment screw to set the height of the seat in an open position.
9. After selecting the raised seat height, tighten the wing nut underneath the bracket to a locked position. To loosen, unscrew the wing nut and set the adjustment screw to the desired position.
10. Lift the foot pedal with your toe to insure that the seat returns to a down position. To regulate the seats speed of descent, loosen or tighten the Phillips head screws attached to the seat clip.
11. To adjust the foot pedal, use a one eighth Allen wrench to set in desired position.